



micro fiber mop and cloth

mop

To begin using the Micro Fiber Mop:

1. Remove the detachable mop pad from the swivel head.

- Dampen the mop pad with water under faucet.
- Wring-out any excess water
- Re-attach the mop pad to the swivel head
- Adjust the extendible handle:
 - Turn top blue part of the handle to the left to loosen
 - Slide it up or down to your desired handle length
 - Turn it to the right to tighten and lock into place.

Mop and clean your floors Amazingly easy!

2. If you have pet hairs, dust balls, lint, etc. on your floors, use the **Micro Fiber Mop** dry for quick and easy pickup!

3. If your floors are very dirty, we recommend that you first use the **Micro Fiber Mop** dry to sweep your floors; then, detach the mop pad from the swivel head and shake off any loose dirt and particles. Dampen the **Micro Fiber Mop** with water and proceed to clean your floors.

cloth

To begin using the Micro Fiber Cloth:

1. First dampen your **Micro Fiber Cloth** with water — wring out any excess water from the cloth so that it is not overly wet.

2. Use the Cloth dry for all of your dusting needs.

3. Try using the Cloth half wet and half dry. Just dampen half of the cloth and keep the other half dry — now you can dust and clean your entire home with just one Cloth.

4. Use **Micro Fiber Cloth** as a floor cloth by attaching cloth to convenient silicone star-tabs on **Micro Fiber Mop**.

Wash and care instructions for all Micro Fiber products:

- Hand or Machine wash cloth
- Air or tumble dry low
- Do not use fabric softeners
- Do not bleach (bleach over time will decrease the quality and effectiveness of the Micro Fibers).
- Do not throw cloths and pads in the wash with terry towels or other fabrics that shed a lot of lint. Wash with jeans, shirts, etc.



Distributed Exclusively Worldwide By:
US Jesco International Ltd., Inc.
1421 Westway Circle
Carrollton, Texas 75006-3733 USA
800-425-3726 • 972-466-0849
Fax 800-492-5888 • 972-242-5888
WWW.USJESCO.COM